
Installation Instruction



UNPACKING INSTRUCTIONS


- Carefully open the carton, remove contents and lay out on cardboard or other protective surface to avoid damage.
- Check package contents against the Supplied Parts List in the next page to assure that all components were received undamaged. Do not use damaged or defective parts.
- Carefully read all instructions before attempting installation.

IMPORTANT SAFETY INFORMATION

- Install and operate this device with care. Please read this instruction before installation, and carefully follow all instructions contained herein. Use proper safety equipment during installation.
- Please call a qualified installation contractor for help if you don't understand these directions or have any doubts about the safety of the installation.

Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaims any and all liability for injury or damage arising from incorrect assembly, incorrect mounting, or incorrect use of this product.


Supplied Parts List



(1) 48mm Tube Support-a



(1) Disconnected "C" Clamp-b



(1) VESA Plate with Arm Assembled-c



(1)Wrench-I



(12)M4x12 Thumb Bolt-d



(12)M4x30 Bolt-e



(24)M4 Washer-f




(12)M4 Space-g



(2)M8x10 Bolt-h



(2)M10x15 Bolt-i



(1)Allen Key-j



(2)Spare Plastic Cover-k

Tools Required

Phillips Screwdriver




CAUTION!

This monitor desktop mount must be securely attached to the horizontal desk. If the mount is not properly installed it may fall, resulting in possible injury and/or damage.


Step 1

Install the "C" Clamp According to the Desktop Thickness




Step 2

Install Arm to the Tube Support




Step 3

Mount the Monitor to VESA Plate




For Flat Back Monitor




For Curved Back Monitor

Step 4

Manager the Wires and Adjust the Turning Tension




Manager the wires by the wire clips, some wires can be hidden inside the pipe.




Remove the plastic cover, use the Allen Key(j) to adjust the turning tension.

Step 5

Fix the Tilt Angle and Adjust the Level of the Monitors



Remove the plastic cover, tighten the nut by the Wrench(I) to fix the tilt angle.



Turn the bolt counterclockwise to lower the center monitor, turn the bolt clockwise to raise the center monitor.